


Helmet Mount Quick Start Guide



FITTING INSTRUCTIONS

1 FITTING AND ADJUSTING HARD HAT OR HELMET



Make sure the helmet sits properly on your head. Choose the correct size for your head.*




Adjust helmet ratchet to fit snug and comfortably.




*Please refer to the helmet manufacturer's instructions for fitting.


2 HELMET MOUNT ADAPTORS (3 different sets included. Use correct adaptor for your style of helmet - see styles below.)



SMHA0000 - MSA V-Gard®



SMHA0001 - Protector AIsafe



SMHA0002 - Protector Tuffmaster

ATTACHING HELMET MOUNT ADAPTORS




Insert helmet mount headset muffs into helmet adaptors. They will slide and snap in.




Insert adaptors into helmet or hard hat until they snap in.



Swivel headset around to face forward.



3 ADJUSTING EARMUFF FIT



Snap helmet mount forks in by placing pressure on each side with your palms. Pressure should be applied at fork angle.



Adjust fit on ear by bracing adaptor with one hand and pulling the earmuff down or up with your other hand. Earmuffs should fit snugly on ears with no gaps. Ear cushions should be slightly compressed when worn correctly. If wearing safety glasses, put them on before adjusting earmuffs.

4 WEARING HELMET MOUNTED HEADSET



Front view



Side view




Back view

QUICK SETUP GUIDE

BASIC HEARING PROTECTION


1 POWER ON/OFF (right earmuff)



Short press to power on. Long press to power off.


Full or partial charge, LED flashes green. Low charge, LED flashes red.

2 SENS VOLUME (right earmuff)



Adjust SENS® audio levels with volume buttons.


3 TURN SHORT-RANGE OFF (right earmuff)



Turn off short-range unless utilizing for small work groups. Short press volume up and down buttons together to toggle off.


ENABLING SHORT-RANGE

1 SHORT-RANGE ON/OFF (right earmuff)




Short press volume up and down buttons together to toggle on/off.

2 SHORT-RANGE TRANSMIT (left earmuff)



Press and hold multi-function button to PTT over short-range.


3 SHORT-RANGE CHANNELS (right earmuff)



Long press volume up or down button to change FM channels.


ENABLING BLUETOOTH (Blue LED is solid in pairing mode and blinks slowly when paired. Short-range must be off when pairing.)

1 BLUETOOTH PAIRING (left earmuff)




Press and hold multi-function button to put headset into pairing mode. "Bluetooth discoverable" when pairing, and connection tone when paired.

2 BLUETOOTH - PHONE CALLS (left earmuff)



Answer call by pressing and releasing MFB. Reject call or end call by pressing and holding MFB.


3 BLUETOOTH - TWO-WAY RADIO (left muff)



Transmit using the radio's PTT. For some devices, MFB will perform as a Bluetooth PTT (if short-range is off).

CABLING TO TWO-WAY RADIO

1 TWO-WAY RADIO CONNECTION



When cabling to two-way radio, make sure radio is off when connecting cable to headset. Connect the Hirose end to the headset and the pin-out end to the radio. Then turn on the radio. Adjust volume with radio's volume controls. Push-to-talk with the cable's in-line PTT or via the radio's PTT button.



sensear.com/product-manuals



Sensear Pty Ltd
4 Hehir Street
Belmont, WA, 6104
Australia
Toll-Free: +61 8 9277 7332

Sensear Inc.
1141 East Main Street
Suite 201
East Dundee, IL 60118
United States
Toll-Free: 1-888-973-6732

sensear.com